

A simple way to clean and disinfect your machine.



Don't accidentally damage your expensive Multifunction Device while trying to clean it!

Many common cleaning products are not safe for cleaning your device. UBEO Business Services, and its affiliates, shall not be responsible for direct, incidental or consequential damages including, but not limited to, damages arising from the improper cleaning of devices.



What you Need

- Microfiber cloth
- Water
- Soap
- Isopropyl Alcohol

**Do not use Isopropyl Alcohol on the screen*

What NOT to Do!!!

- DO NOT wipe down your machine's screen with isopropyl alcohol or a disinfectant wipe. This can damage your device's screen and remove the coating that protects your device from oils and grease.
- DO NOT let any water or moisture into openings, any ports, speakers, switches or elsewhere.

What to Do

- Turn off your device and unplug it.
- Screen is sensitive and should only be cleaned with a soft, slightly damp, lint-free microfiber cloth.
- If your Screen is still visibly dirty or germs are of concern, use a soft, lint-free cloth with warm soapy water.
- The plastic and outside of the machine can be cleaned with a soft lint free cloth and isopropyl alcohol.
- Make sure everything is dry before plugging the machine back in and turning on the device.